



User Guide

MMS7xx-x1 All-In-One Servo Motors

MMP7xx-x1 Driver Modules

Table of Contents

| | |
|--|----|
| Overview | 3 |
| Introduction | 3 |
| Applicable Products..... | 3 |
| Safety Warnings | 4 |
| Section 1. Hardware | 5 |
| 1.1 Connections | 5 |
| 1.2 Power | 5 |
| 1.3 Control Interface..... | 5 |
| 1.3.1 I/O Interface | 6 |
| 1.3.2 RS-485 Interface..... | 7 |
| 1.4 Mechanical Mounting | 8 |
| Section 2. Communication | 9 |
| 2.1 Communication Protocol | 9 |
| 2.1.1 Read Holding Registers (0x03)..... | 9 |
| 2.1.2 Write Single Register (0x06)..... | 10 |
| 2.1.3 Write Multiple Registers (0x10)..... | 10 |
| Section 3. Operational Modes | 12 |
| 3.1 Position Control Mode | 12 |
| 3.1.1 RS-485 Control Mode | 12 |
| 3.1.2 STEP/DIR Control Mode..... | 13 |
| 3.2 Speed Control Mode | 13 |
| 3.2.1 RS-485 Control Mode | 13 |
| 3.2.2 PWM/DIR Control Mode | 14 |
| 3.3 Torque Control Mode | 15 |
| 3.3.1 RS-485 Control Mode | 15 |
| 3.3.2 PWM/DIR Mode..... | 15 |
| 3.4 Homing Mode | 15 |
| 3.5 Fault Indication | 17 |
| Section 4. MotionLAB | 18 |
| Section 5. Register Map | 19 |
| Section 6. Register Details..... | 21 |

Overview

Introduction

The MMS7xx-x1 all-in-one servo motors are fully integrated solutions for motion control applications. They integrate a position sensor, controller, and driver inside the motor housing to provide a complete smart motor solution.

The motors can operate in speed, position, or torque control modes. The motors are controlled through either an RS-485 serial interface, or the simple input/output (I/O) interface (see Figure 1). Configurable parameters can be set with an easy-to-use, PC-based program, which interfaces to the motor through the USB and RS-485 interface. Once parameters have been optimized, they can be saved in the motor's non-volatile memory (NVM).




Figure 1: Motor Control Block Diagram

In addition to complete motor assemblies, a driver module is also available. The MMP7xx-x1 driver module offers a control and drive solution that can be integrated with other motors.

The MMP7xx-x1 driver module includes a magnetic position sensor for rotor feedback, a field-oriented-control (FOC) motor controller, and a power stage.

Applicable Products

Table 1 lists the products that are applicable to this user guide.

Table 1: Applicable Products

| All-In-One Servo Motors | | Driver Module | |
|-------------------------|-------------------|---------------|-------------------|
| MMS7xx-R1 | MMS757188-36-R1-1 | MMP7xx-R1 | MMP757188-70-R1-1 |
| | MMS757141-36-R1-1 | | MMP757141-70-R1-1 |
| | MMS757094-36-R1-1 | | MMP757094-70-R1-1 |
| | MMS742038-24-R1-1 | | MMP742038-36-R1-1 |
| | MMS742052-24-R1-1 | | MMP742052-36-R1-1 |
| | MMS742077-24-R1-1 | | MMP742077-36-R1-1 |
| | MMS742105-24-R1-1 | | MMP742105-36-R1-1 |
| MMS7xx-S1 | MMS757188-36-S1-1 | MMP7xx-S1 | MMP757188-70-S1-1 |
| | MMS757141-36-S1-1 | | MMP757141-70-S1-1 |
| | MMS757094-36-S1-1 | | MMP757094-70-S1-1 |
| | MMS742038-24-S1-1 | | MMP742038-36-S1-1 |
| | MMS742052-24-S1-1 | | MMP742052-36-S1-1 |
| | MMS742077-24-S1-1 | | MMP742077-36-S1-1 |
| | MMS742105-24-S1-1 | | MMP742105-36-S1-1 |

Safety Warnings

To prevent personal injury or damage to the motor or other equipment, follow the guidelines listed below:

- Always secure the motor before applying power, since the motor may move unexpectedly, jump, or fall when it starts.
- Keep hair and loose clothing away from the motor.
- Avoid the shaft and any attached mechanical parts when operating the motor.
- Do not open or disassemble the motor.
- Bond the motor enclosure to a protective ground when the motor is installed in a system.
- Ensure that the power source connected to the motor is fused or otherwise current-limited.

Section 1. Hardware

1.1 Connections

Power and control connections are made to the rear surface of the motor. LEDs indicate the presence of power, or whether a fault condition has occurred (see Figure 2).




Figure 2: The Rear Surface of the Motor

Table 2 lists matching connectors. Users can find the accessory package on www.EZmotion.co. For example, the MMA03-3001 provides all of the connectors listed below.

Table 2: Matching Connectors

| Connector | Pins | Manufacturer | Part Number |
|-----------|------|--------------|-------------------|
| IO | 5 | KAIFENG | KF12EKD-2.5-5P-1G |
| RS-485 | 4 | KAIFENG | KF12EKD-2.5-4P-1G |
| Power | 3 | KAIFENG | KF12EKD-2.5-3P-1G |

1.2 Power

DC power is connected to the motor through the 3-pin connector on the rear of the motor housing (see Figure 3). Apply a DC voltage within the model's specification range. The power supply should be fused or current-limited, and it must be capable of supplying current up to the motor's target current limit




Figure 3: DC Power Connector

The R- pin can be connected to an external power resistor and VIN. The external resistor can limit the bus voltage by dissipating energy when energy is returned from the motor. This can occur during regenerative braking or other conditions when the mechanical energy is converted to electrical energy.

1.3 Control Interface

The MMS7xx-S1 servo motor and MMP7xx-S1 driver module are controlled by the I/O interface, which means that they only accept control signals from the I/O interface. The RS-485 interface in the MMS7xx-S1 and MMP7xx-S1 is used for debugging and reading/writing registers.

The MMS7xx-R1 servo motor and MMP7xx-R1 driver module may be controlled either using high-level commands through an RS-485 interface, or by using a simple I/O interface.

1.3.1 I/O Interface

The I/O interface is optically isolated (see Figure 4).




Figure 4: I/O Interface

Table 3 shows the signals used by the I/O interface.

Table 3: I/O Interface Signals

| Signal | Direction | Pin | Description |
|--------|---------------|-----|---|
| COM- | Bidirectional | 1 | Common return. |
| DI1+ | To motor | 2 | Default: ENA. Enables the motor when driven high. Alternate: Home switch, negative switch, or positive switch. |
| DO1+ | From motor | 3 | Default: PEND. Driven active when the position is reached. Alternate: ALARM. |
| DI2+ | To motor | 4 | Default: STEP, or PWM input to control position or speed. Alternate: Home switch, negative switch, or positive switch. |
| DI3+ | To motor | 5 | Default: DIR. Sets CW rotation direction when driven high. Alternate: Home switch, negative switch, or positive switch. |

Figure 5 shows the internal circuitries connected to these signals.




Figure 5: Internal Circuitries of the I/O Interface

The I/O interface supports STEP/DIR control for position mode, and PWM/DIR control for speed and torque mode. The STEP or PWM signal is input via the DI2+ pin. The rotation direction is set by the state of the DI3 input signal, and motion is enabled or disabled by the DI1 signal.

When the motion is complete, the DO1 signal goes active to indicate that the motor has completed the motion.

1.3.2 RS-485 Interface

Figure 6 on page 7 shows the RS-485 control interface.




Figure 6: RS-485 Control Interface

Table 4 lists the RS-485 control interface signals.

Table 2: RS-485 Control Interface Signals

| Signal | Direction | Pin | Description |
|--------|---------------|-----|---|
| EXT_5V | To motor | 1 | External 5V power for firmware configurations |
| B | Bidirectional | 2 | RS-485 data B (inverting) |
| AGND | N/A | 3 | Ground for EXT_5V |
| A | Bidirectional | 4 | RS-485 data A (non-inverting) |

The RS-485 has an asynchronous serial interface, and uses standard RS-485 transceivers. The baud rate is set to 115200bps by default, but this value can be changed by writing to the BAUDRATE register.

The module supports multi-slave communication. The slave address can be configured by writing to the RS485_ADDR register, which is available from 0x00 to 0x7F. Address 0x00 is the broadcast address, meaning that all slaves respond when the master uses 0x00 as the slave address.

The registers can be read and written to via the MotionLAB software tool (see Section 4 on page 17 for more details).

The master address is the address that the communication kit (or other master) uses. For successful communication, the master request address and slave address should be the same.

To communicate with the module without applying the main VIN power (e.g. to configure the NVM), supply 5V DC to the EXT-5V pin. This pin is not connected during normal operation.

Figure 7 shows the connection between a master controller and the MMS7xx-R1 series motor (or MMP7xx-R1 series module).




Figure 7: The Internal Circuitry of the RS-485 Control Interface

1.4 Mechanical Mounting

The MMS7xx-x1 series motors are mechanically mounted from a front flange, such as NEMA frame motors. For mounting dimensions, refer to the specifications for each motor.

The MMP7xx-x1 series modules are designed to mount to the back of standard NEMA motors. Refer to the specification for each module for more details.

Section 2. Communication

The motor/driver module uses the MODBUS RTU protocol to exchange messages between the master and slave nodes. A master-slave system has one node (the master node) that issues explicit commands to one of the slave nodes, and does not communicate with other slaves. The slave node never transmits data unless it has received a request from the master node. The slave nodes never communicate with each other.

In the module, control parameters are stored as discontinuous holding registers. They can be accessed using the MODBUS function codes 0x03 (read holding registers), 0x06 (write single register), and 0x10 (write multiple registers).

2.1 Communication Protocol

The data frame format contains an address field, a function code, data, and a CRC (see Figure 8). For each byte in the data frame, the data format is 8 data bits, 1 stop bit, and 1 odd polarity check bit.



Figure 8: MODBUS RTU Data Frame

MODBUS allows for 256 different addresses. Address 0 is the broadcast address; all slave nodes recognize the broadcast address. Addresses 1–247 are valid individual addresses, and addresses 248–255 are reserved.

An exception response is sent when a communication error is detected. Figure 9 shows the exception data frame format.



Figure 9: MODBUS Exception Data Frame

For the supported function codes, the data field is defined in the following sections.

2.1.1 Read Holding Registers (0x03)

This function code is used to read the contents of holding registers in a slave device.

All the registers in the module are 16 bits in length, which occupies one holding register. The data format for the request, response, and error frames are below.

Request

| Slave Address | Function Code | Register Address | | Quantity of Registers | | CRC |
|---------------|---------------|------------------|----------|-----------------------|----------|---------|
| 1 Byte | 0x03 | High Byte | Low Byte | High Byte | Low Byte | 2 Bytes |

Response

| Slave Address | Function Code | Number of Bytes Returned | Register Value 1 | | | CRC |
|---------------|---------------|--------------------------|------------------|----------|-------|---------|
| 1 Byte | 0x03 | 1 Byte | High Byte | Low Byte | | 2 Bytes |

Error

| Slave Address | Error Code | Exception Code | CRC |
|---------------|-------------|------------------------------|---------|
| 1 Byte | 0x80 + 0x03 | 0x01 or 0x02 or 0x03 or 0x04 | 2 Bytes |

Table 5 on page 9 shows an example of a read register.

Table 5: Read Register IQ_LATCH (0x63) using Slave Address 0x01

| Request | | Response | |
|------------------------------|------------|-----------------------|------------|
| Field Name | Data (Hex) | Field Name | Data (Hex) |
| Address | 0x01 | Address | 0x01 |
| Function Code | 0x03 | Function Code | 0x03 |
| Starting Address (High) | 0x00 | Byte Count | 0x02 |
| Starting Address (Low) | 0x63 | Register Value (High) | 0x00 |
| Quantity of Registers (High) | 0x00 | Register Value (Low) | 0x00 |
| Quantity of Registers (Low) | 0x01 | CRC (Low) | 0xB8 |
| CRC Low | 0x74 | CRC (High) | 0x44 |
| CRC High | 0x14 | - | - |

2.1.2 Write to a Single Register (0x06)

This function code is used to write a single holding register in a slave device. The data format for the request, response, and error frames are below.

Request

| Slave Address | Function Code | Register Address | | Value to Write | | CRC |
|---------------|---------------|------------------|----------|----------------|----------|---------|
| 1 Byte | 0x06 | High Byte | Low Byte | High Byte | Low Byte | 2 Bytes |

Response

| Slave Address | Function Code | Register Address | | Written Value | | CRC |
|---------------|---------------|------------------|----------|---------------|----------|---------|
| 1 Byte | 0x06 | High Byte | Low Byte | High Byte | Low Byte | 2 Bytes |

Error

| Slave Address | Error Code | Exception Code | CRC |
|---------------|-------------|------------------------------|---------|
| 1 Byte | 0x80 + 0x06 | 0x01 or 0x02 or 0x03 or 0x04 | 2 Bytes |

Table 6 lists an example of a write register.

Table 6: Write Register SPD_KP (0x22) using Slave Address 0x01

| Request | | Response | |
|------------------------------|------------|-------------------------|------------|
| Field Name | Data (Hex) | Field Name | Data (Hex) |
| Address | 0x01 | Address | 0x01 |
| Function Code | 0x06 | Function Code | 0x06 |
| Starting Address (High) | 0x00 | Starting Address (High) | 0x00 |
| Starting Address (Low) | 0x22 | Starting Address (Low) | 0x22 |
| Quantity of Registers (High) | 0xFD | Register Value (High) | 0xFD |
| Quantity of Registers (Low) | 0xFE | Register Value (Low) | 0xFE |
| CRC (Low) | 0xE8 | CRC (Low) | 0xE8 |
| CRC (High) | 0xD0 | CRC (High) | 0xD0 |

2.1.3 Write to Multiple Registers (0x10)

This function code writes to a block of continuous registers in a slave device. This function can be used to write 32-bit control parameters with register length of 2.

Request

| | | | | | | | |
|---------------|---------------|------------------------|-----------------|------------|------------------|-------|---------|
| Slave Address | Function Code | Start Register Address | Register Number | Byte Count | Register Value 1 | | CRC |
| 1 Byte | 0x10 | 2 Bytes | 2 Bytes | 1 Byte | 2 Bytes | | 2 Bytes |

Response

| | | | | | | |
|---------------|---------------|------------------------|----------|-----------------|----------|---------|
| Slave Address | Function Code | Start Register Address | | Register Number | | CRC |
| 1 Byte | 0x10 | High Byte | Low Byte | High Byte | Low Byte | 2 Bytes |

Error

| | | | |
|---------------|-------------|------------------------------|---------|
| Slave Address | Error Code | Exception Code | CRC |
| 1 Byte | 0x80 + 0x10 | 0x01 or 0x02 or 0x03 or 0x04 | 2 Bytes |

Table 6 lists an example of a write to multiple registers.

Table 6: Write POS_CMD (0x4A and 0x4B) to Slave 0x01

| Request | | Response | |
|-------------------------|------------|-------------------------|------------|
| Field Name | Data (Hex) | Field Name | Data (Hex) |
| Address | 0x01 | Address | 0x01 |
| Function code | 0x10 | Function code | 0x10 |
| Starting Address (High) | 0x00 | Starting Address (High) | 0x00 |
| Starting Address (Low) | 0x4A | Starting Address (Low) | 0x4A |
| Register Number (High) | 0x00 | Register Number (High) | 0x00 |
| Register Number (Low) | 0x02 | Register Number (Low) | 0x02 |
| Bytes to Write | 0x04 | CRC (Low) | 0x60 |
| Value to Write (High) | 0x00 | CRC (High) | 0x1E |
| Value to Write (Low) | 0x01 | - | - |
| Value to Write (High) | 0x00 | - | - |
| Value to Write (Low) | 0x00 | - | - |
| CRC (Low) | 0x26 | - | - |
| CRC (High) | 0x20 | - | - |

Section 3. Operational Modes

3.1 Position Control Mode

3.1.1 RS-485 Control Mode

The RS-485 control mode is for the MMS7xx-R1 and MMP7xx-R1 only. Using RS-485 control, the position mode can be configured in absolute command mode or incremental command mode. The mode is set through the POS_CMD_TYPE register. Absolute mode commands the motor to an absolute position, while the incremental command moves the motor relative to its current position.

In absolute command mode, the maximum command limit is $\pm 32,768$ mechanical revolutions. In incremental command mode, the minimum command resolution should exceed 0.2° due to the internal position sensor's resolution limitations.

The command is set through the POS_CMD register (0x4A and 0x4B) (see Table 7). In this table, Revs is the target position for command full revolutions, and Theta is the target position command's angle.

Table 7: POS_CMD Register

| Forward Direction | Reverse Direction |
|---|--|
| POS_CMD, bits[31:0] = $(\text{Revs} + \text{Theta} / 360) \times 2^{16}$ 0x4A, bits[15:0] = POS_CMD, bits[31:16] 0x4B, bits[15:0] = POS_CMD, bits[15:0] | POS_CMD, bits[31:0] = $2^{32} - (\text{Revs} + \text{Theta} / 360) \times 2^{16}$ 0x4A, bits[15:0] = POS_CMD, bits[31:16] 0x4B, bits[15:0] = POS_CMD, bits[15:0] |

Table 8 shows an example when the position is set to 2 revolutions plus 45° .

Table 8: POS_CMD Register Example

| Forward Direction | Reverse Direction |
|--|---|
| 0x4A, bits[15:0] = 2 = 0002h 0x4B, bits[15:0] = $45/360 \times 2^{16} = 2000\text{h}$ | 0x4A, bits[15:0] = $2^{16} - 2 = \text{FFFDh}$ 0x4B, bits[15:0] = $2^{16} - 45/360 \times 2^{16} = \text{E000h}$ |

After a new position command is given in position mode, the reference generation block inside the device calculates the position curve every $100\mu\text{s}$ to make the motion smooth (see Figure 10).




Figure 1: Position Reference Profile

If the speed limit has not been reached, and there is enough angle left for the motor to decrease the speed and stop, the motor either increases its speed or maintains its speed. When the speed reaches the speed limit, the motor limits the speed at the set value. If the reference generation block detects that the remaining angle is not enough for the motor to ramp down the speed using the set speed slope, the generation block slows the motor so that the speed is zero once the position is reached.

If a new position command is given when the motor speed is ramping down, the reference generation block increases the motor speed again to ensure that the motor reaches the target position as quickly as possible.

The position mode slope is set via the PROFILE_ACCE (0x4F) and SPD_CMD (0x4D and 0x4E) registers. PROFILE_ACCE sets the speed ramp slope in position mode. SPD_CMD sets the position ramp slope, which is the same as the speed limit (the default value is 3000rpm).

Write 0x0000 to register 0x76 to update the position command.

3.1.2 STEP/DIR Control Mode

The STEP/DIR control mode is for all applicable products listed in Table 1 on page 3.

In STEP/DIR command control mode, the position works in incremental mode. Each rising edge on the STEP input moves the motor by a configurable increment. The number of steps per revolution can be configured to 512, 1024, 2048, or 4096 steps per mechanical revolution. This is set through the NSTEP register. The default value is 4096.

The number of steps per revolution can also be set by the on-board switch (SW1). NSTEP_TYPE (register 0x34, bit[7]) determines whether the steps per revolution is set via the register value or the switch status. Table 9 lists the relationship between the SW1 status and the number of steps per revolution. Note that pin 1 of SW1 should be off all the time.

Table 9: Relationship Between SW1 Status and Steps per Revolution

| Pin 2 Status | Pin 3 Status | Pin 4 Status | Steps per Revolution |
|--------------------|--------------|--------------|---------------------------|
| On | On | On | 4096 steps per revolution |
| On | On | Off | 2048 steps per revolution |
| On | Off | On | 1024 steps per revolution |
| On | Off | Off | 512 steps per revolution |
| Other combinations | | | 512 steps per revolution |

To smoothly ramp the speed of the motor, the velocity up/down slope can be configured through the PROFILE_ACCE register.

The loop parameters can be optimized through the KP_POS and KP_GAIN_POS registers, according to the system requirements with the real mechanical load.

The maximum torque limit can be configured via the MAX_LIMIT_IQ register.

3.2 Speed Control Mode

3.2.1 RS-485 Control Mode

RS-485 control mode is for the MMS7xx-R1 and MMP7xx-R1 only. In speed control mode, the speed command (in rpm) is set through the RS-485 interface. The command is set through the SPD_CMD register (0x4D and 0x4E) (see Table 10 on page 13). In Table 10, Speed is the target speed (in rpm).

Table 10: SPD_CMD Register

| Forward Direction | Reverse Direction |
|--|--|
| SPD_CMD, bits[31:0] = (Speed / 60) x 2 ³² / 10,000 0x4D = SPD_CMD, bits[31:16] 0x4E = SPD_CMD, bits[15:0] | SPD_CMD, bits[31:0] = 2 ³² - (Speed / 60) x 2 ³² / 10,000 0x4D = SPD_CMD, bits[31:16] 0x4E = SPD_CMD, bits[15:0] |

Table 11 lists how to set the speed to 3,000rpm.

Table 11: SPD_CMD Register Example

| Forward Direction | Reverse Direction |
|---|---|
| SPD_CMD, bits[31:0] = (3,000 / 60) x 2 ³² / 10,000 = 0147AE14h 0x4D = SPD_CMD, bits[31:16] = 0147h 0x4E = SPD_CMD, bits[15:0] = AE14h | SPD_CMD, bits[31:0] = 2 ³² - ((3,000 / 60) x 2 ³² / 10,000) = FFFCB965h 0x4D = SPD_CMD, bits[31:16] = FFFCh 0x4E = SPD_CMD, bits[15:0] = B965h |

In speed mode, the velocity ramp up/down slope can be configured via the PROFILE_ACCE register. After updating the speed reference, the motor speed ramps to the target speed using the set slope rate. If the slope rate setting changes during ramping, the actual slope rate changes immediately, and the motor changes speed according to the newly set ramp slope.




Figure 11: Speed Reference Profile

The loop parameters can be optimized via registers KP_SPD, KP_GAIN_SPD, KI_SPD, KI_GAIN_SPD, and KC_SPD, based on the real mechanical load.

The maximum torque limit can be configured via MAX_LIMIT_IQ. For more details, see the Torque Control Mode section on page 14.

Write 0x0000 to register 0x76 to update the speed command.

3.2.2 PWM/DIR Control Mode

PWM/DIR control mode is for all applicable products listed in Table 1 on page 3.

In PWM/DIR command control mode, the motor speed is controlled by the duty cycle of the PWM input. The real motor speed is (SPD_CMD x Duty Cycle), and the SPD_CMD can be configured (registers 0x4D and 0x4E). The PWM signal frequency should be between 100Hz and 10kHz.

The DIR pin can control the direction. When DIR is at a high level, the motor moves clockwise.

3.3 Torque Control Mode

3.3.1 RS-485 Control Mode

RS-485 control mode is for the MMS7xx-R1 and MMP7xx-R1 only. In torque control mode, the torque command (which corresponds to the phase current) is set directly through the RS-485 interface; otherwise, it is set through the IQ_CMD register.

If the torque current (I_Q) is positive, IQ_CMD, bits[11:0] can be calculated with Equation (1):

$$\text{IQ_CMD, bits[11:0]} = I_Q \times 1.5 \times 0.01 \times K_{AD} \times 1024 / 1.6 \quad (1)$$

Where K_{AD} is the amplifier gain coefficient for current-sensing. If I_Q is negative, IQ_CMD, bits[11:0] can be calculated with Equation (2):

$$\text{IQ_CMD, bits[11:0]} = 2^{12} - (I_Q \times 1.5 \times 0.01 \times K_{AD} \times 1024 / 1.6) \quad (2)$$

Check the corresponding specification for the actual amplifier gain coefficient.

Below is an example to set a 5A torque current when the amplifier gain is 2.

If I_Q is positive, IQ_CMD, bits[11:0] can be calculated with Equation (3):

$$\text{IQ_CMD, bits[11:0]} = 5 \times 1.5 \times 0.01 \times 2 \times 1024 / 1.6 = 60h \quad (3)$$

If I_Q is negative, IQ_CMD, bits[11:0] can be calculated with Equation (4):

$$\text{IQ_CMD, bits[11:0]} = 2^{12} - (5 \times 1.5 \times 0.01 \times 2 \times 1024 / 1.6) = FA0h \quad (4)$$

3.3.2 PWM/DIR Mode

PWM/DIR control mode is for all applicable products listed in Table 1 on page 3.

In PWM/DIR command control mode, the motor torque is controlled by the duty cycle of the PWM input. The real motor torque is (IQ_CMD x Duty Cycle), where IQ_CMD can be configured via register 0x2F. The PWM signal frequency should be between 100Hz and 10kHz. The DIR pin can control the torque direction. When DIR is at a high level, the torque is positive, which means the motor tries to rotate clockwise.

In torque mode, the maximum speed clamp can be configured via the T_MAX_SPD and ANTI_TORQUE_GAIN registers. The loop parameters can be optimized through the CURRENT_KP and CURRENT_KI registers.

3.4 Homing Mode

Homing mode is used for seeking the home position (also called the datum, reference point, or zero point). There are various methods to achieve this function using a limit switch at the ends of travel, or a home switch (zero-point switch) at the middle of travel. Most of the methods also use the index (zero) pulse from an angle sensor. Homing with limited torque methods are also supported. These methods are not required to limit switch signals, which can simplify the system and lower the cost.

The user should specify the speed, acceleration, and the method of homing. There are two homing speeds; typically, the faster speed is used to find the home switch (homing speed switch), while the slower speed is used to find the index pulse (homing speed zero).

The controller supports methods 1 to 14, 17 to 30, 33, and 34, as defined in CiA DSP 402 standard. In addition, the controller supports homing with torque limit methods. Table 12 on page 15 shows the detailed descriptions and illustrations of these methods.

Table 12: Homing Methods

| Method | Description | Diagram |
|-------------|--|--|
| -3 | Homing clockwise with a limited torque. | <p>These two methods allow for homing without a limit switch or home switch. The motor goes in one direction until it reaches the mechanical range limit. The motor output torque is limited by the homing torque.</p> |
| -2 | Homing counterclockwise with a limited torque. | |
| 1 | Homing on a negative limit switch and index pulse. | |
| 2 | Homing on a positive limit switch and index pulse. | |
| 3, 4 | Homing on a positive home switch and index pulse. | |
| 7, 8, 9, 10 | Homing on a home switch and index pulse (positive initial motion). | |

| | | |
|-----------------------|--|--|
| <p>11, 12, 13, 14</p> | <p>Homing on a home switch and index pulse (negative initial motion).</p> | |
| <p>17–30</p> | <p>These methods are similar to methods 1–14, except that the home position is not dependent on the index pulse. It is only dependent on the relevant home or limit switch transitions. For example, methods 19 and 20 are similar to methods 3 and 4.</p> | |
| <p>33, 34</p> | <p>Homing on the index pulse.</p> | |

3.5 Fault Indication

The control module has robust protections to avoid unexpected failure modes and external component damage. The fault type can be determined either from the register value 0x53 or from the red LED flash times (see Table 13).

Table 13: Fault Indication

| Fault Type | Register 0x53 Flag Bit | LED Flash Times |
|------------------|------------------------|-----------------|
| OCP | Bit[2] | 3 |
| Rotor lock | Bit[3] | 4 |
| Overload | Bit[4] | 5 |
| Over-temperature | Bit[5] | 6 |

Section 4. MotionLAB

The MMS7xx-x1 series motors are pre-configured with initial parameters, so the motor can simply be connected to power and to a PC (via the USB to RS-485 interface) to spin the motor.

EZmotion provides a user-friendly, PC-based virtual bench GUI software, MotionLAB, which offers an easy way to configure and monitors the performance of the motor and module (see Figure 12).




Figure 12: MotionLAB

Download the MotionLAB software and its driver installer from the EZmotion website. The user guide for MotionLAB is also available on the website.

Install MotionLAB and its driver. Read its user guide carefully before using MotionLAB software to run the motor.

Section 5. Register Map

| Addr | D[15:0] |
|-------------------------------|---------------------------------|
| Position Command | |
| 1Eh | POS_THRESHOLD, bits[15:0] |
| 4Ah | POS_CMD, bits[31:16] |
| 4Bh | POS_CMD, bits[15:0] |
| 50h | NSTEP, bits[15:0] |
| Position Loop Settings | |
| 1Ah | KP_POS, bits[15:0] |
| 1Bh | KP_GAIN_POS, bits[15:0] |
| 1Ch | SPEED_LIMIT, bits[15:0] |
| Speed Commands | |
| 29h | SPD_THRESHOLD, bits[15:0] |
| 4Dh | SPD_CMD, bits[31:16] |
| 4Eh | SPD_CMD, bits[15:0] |
| 4Fh | PROFILE_ACCE, bits[15:0] |
| Speed Loop Settings | |
| 22h | KP_SPD, bits[15:0] |
| 23h | KP_GAIN_SPD[15:0] |
| 24h | KI_SPD, bits [15:0] |
| 25h | KI_GAIN_SPD, bits[15:0] |
| 26h | KC_SPD, bits[15:0] |
| 27h | MAX_LIMIT_IQ, bits[11:0] |
| Torque Command | |
| 2Fh | IQ_CMD, bits[11:0] |
| Torque Loop Settings | |
| 2Dh | T_MAX_SPD, bits[15:0] |
| 2Eh | ANTI_TORQUE_GAIN, bits[15:0] |
| 43h | CURRENT_KP, bits[15:0] |
| 44h | CURRENT_KI, bits[15:0] |
| Homing Mode Parameters | |
| 30h | DO1_FUNCTION, bits[15:0] |
| 31h | DI2_FUNCTION, bits[15:0] |
| 32h | DI1_FUNCTION, bits[15:0] |
| 33h | DI3_FUNCTION, bits[15:0] |
| 35h | IO_POLARITY, bits[15:0] |
| 39h | HOMING_METHOD, bits[15:0] |
| 3Ah | HOMING_SPEED_SWITCH, bits[15:0] |
| 3Bh | HOMING_SPEED_ZERO, bits[15:0] |
| 3Ch | HOMING_TORQUE, bits[15:0] |
| 3Dh | HOMING_STALL_TIME, bits[15:0] |
| 45h | HOMING_ACCE, bits[15:0] |
| 48h | HOMING_OFFSET_ROUND, bits[15:0] |
| 49h | HOMING_OFFSET_ANGLE, bits[15:0] |
| Operating Mode | |
| 34h | CONFIG, bits[15:0] |

| Protection Parameters | |
|------------------------------|-----------------------------|
| 53h | ERROR_STATUS, bits[15:0] |
| 54h | RETRY, bits[15:0] |
| 55h | PROTECTION, bits[15:0] |
| 56h | VDC_LIMIT, bits[15:0] |
| 58h | DEADTIME[15:0] |
| 59h | ADGAIN, bits[15:0] |
| 5Ah | IOCP, bits[15:0] |
| 5Bh | V_UVLO, bits[15:0] |
| 6Bh | OVERTEMP, bits[15:0] |
| Switching Frequency | |
| 57h | FSW, bits[15:0] |
| RS-485 Communication | |
| 5Ch | RS485_ADDR, bits[15:0] |
| 5Dh | RS485_BAUDRATE, bits[15:0] |
| Servo Information | |
| 5Eh | TEMPERATURE, bits[15:0] |
| 5Fh | POSITION, bits[31:16] |
| 60h | POSITION, bits[15:0] |
| 61h | SPEED, bits[15:0] |
| 62h | SPEED, bits[31:16] |
| 63h | IQ_LATCH, bits[15:0] |
| 64h | ID_LATCH, bits[15:0] |
| 65h | UQ_LATCH, bits[15:0] |
| 66h | UD_LATCH, bits[15:0] |
| 6Ah | STATUS, bits[15:0] |
| 6Ch | VIN_SENSE, bits[15:0] |
| Operating Command | |
| 70h | RUN, bits[15:0] |
| 71h | BRAKE, bits[15:0] |
| 73h | LOAD_TO_FLASH, bits[15:0] |
| 74h | LOAD_FROM_FLASH, bits[15:0] |
| 76h | UPDATE_COMMAND, bits[15:0] |

Section 6. Register Details

Position Commands

| 0x1E: POS_THRESHOLD | | | |
|---------------------|---------------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | POS_THRESHOLD | 0024h | Sets the position to reach the target threshold (LSB). 1 LSB = 360 / 65536°. The target is reached when the target position and the real feedback position error are below this value. |

| 0x4A: POS_CMD, Bits[31:16] | | | |
|----------------------------|---------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | POS_CMD | 0000h | Position command (higher 16 bits), calculated with the following equation: $\text{POS_CMD, bits}[31:0] = (\text{Revolutions} + \text{Theta} / 360) \times 2^{16}$ 0x4A, bits[15:0] = POS_CMD, bits[31:16] |

| 0x4B: POS_CMD, Bits[15:0] | | | |
|---------------------------|---------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | POS_CMD | 0000h | Position command (lower 16 bits), calculated with the following equation: $\text{POS_CMD, bits}[31:0] = (\text{Revolutions} + \text{Theta} / 360) \times 2^{16}$ 0x4B, bits[15:0] = POS_CMD, bits[15:0] |

| 0x50: NSTEP | | | |
|-------------|-------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | NSTEP | 0004h | Sets the stepping resolution per step input. 4: 4096 steps per revolution 5: 2048 steps per revolution 6: 1024 steps per revolution 7: 512 steps per revolution |

Position Loop Settings

| 0x1A: KP_POS | | | |
|--------------|--------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | KP_POS | 00FAh | Sets the position loop proportional gain. |

| 0x1B: KP_GAIN_POS | | | |
|-------------------|-------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | KP_GAIN_POS | 8008h | Sets the gain ratio of the position loop proportional gain. |

| 0x1C: SPEED_LIMIT | | | |
|-------------------|-------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | SPEED_LIMIT | 02FFh | Sets the maximum speed in position mode. The unit is LSB / 100µs, with 2 ¹⁶ LSBs per revolution. In the calculation below, the speed limit is set to 3,000rpm: $\text{SPEED_LIMIT} = 3000(\text{rpm}) \times 2^{16} / 60 / 10,000$ |

Speed Commands

| 0x29: SPD_THRESHOLD | | | |
|---------------------|---------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | SPD_THRESHOLD | 0006h | Sets the speed to reach the target threshold (LSB/100µs). 1 LSB / 100µs = 9.155rpm. The target is reached when the target speed and real feedback speed error are below this value. |

| 0x4D: SPD_CMD, Bits[31:16] | | | |
|----------------------------|---------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | SPD_CMD | 000Ah | Speed command (higher 16 bits). The speed in forward direction can be calculated with the following equation: $\text{SPD_CMD, bits[31:0]} = \text{Speed} / 60 \times 2^{32} / 10,000$ The speed in reverse direction can be calculated with the following equation: $\text{SPD_CMD bits[31:0]} = 2^{32} - (\text{Speed} / 60 \times 2^{32} / 10,000)$ 0x4D = SPD_CMD, bits[31:16]. |

| 0x4E: SPD_CMD, Bits[15:0] | | | |
|---------------------------|---------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | SPD_CMD | 0000h | Speed command (lower 16 bits). The speed in forward direction can be calculated with the following equation: $\text{SPD_CMD, bits[31:0]} = \text{Speed(rpm)} / 60 \times 2^{32} / 10,000$ The speed in reverse direction can be calculated with the following equation: $\text{SPD_CMD, bits[31:0]} = 2^{32} - (\text{Speed(rpm)} / 60 \times 2^{32} / 10,000)$ 0x4E = SPD_CMD, bits[15:0]. |

| 0x4F: PROFILE_ACCE | | | |
|--------------------|--------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | PROFILE_ACCE | 1300h | Sets the profile acceleration for the position and speed trajectory generator (in LSB / 100µs / 100µs, with 2 ¹⁶ LSBs per revolution). Calculate the slope with N (in rpm/ms) using the following equation: $\text{PROFILE_ACCE} = N(\text{rpm/ms}) \times 2^{16} \times 2^{16} / 6,000,000$ |

Speed Loop Settings

| 0x22: KP_SPD | | | |
|--------------|--------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | KP_SPD | FDE8h | Sets the gain ratio for the speed loop proportional gain. It is recommended to use MotionLAB software to set the loop parameters. |

| 0x23: KP_GAIN_SPD | | | |
|-------------------|-------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | KP_GAIN_SPD | 8009h | Sets the gain ratio for the speed loop proportional gain. It is recommended to use MotionLAB software to set the loop parameters. |

| 0x24: KI_SPD | | | |
|--------------|--------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | KI_SPD | 0309h | Sets the speed loop integral gain. It is recommended to use MotionLAB software to set the loop parameters. |

| 0x25: KI_GAIN_SPD | | | |
|-------------------|-------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | KI_GAIN_SPD | 8013h | Sets the gain ratio for the speed loop proportion gain. It is recommended to use MotionLAB software to set the loop parameters. |

| 0x26: KC_SPD | | | |
|--------------|--------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | KC_SPD | 0032h | Sets the speed loop anti-integral gain. It is recommended to use MotionLAB software to set the loop parameters. |

| 0x27: MAX_LIMIT_IQ | | | |
|--------------------|--------------|---------|---|
| Bits | Name | Default | Description |
| 11:0 | MAX_LIMIT_IQ | 03FFh | <p>Sets the maximum torque current limit for the speed loop output.</p> <p>If I_Q is positive, the limit can be calculated with the following equation:</p> $\text{MAX_LIMIT_IQ, bits}[11:0] = I_Q \times 1.5 \times 0.01 \times K_{AD} \times 1024 / 1.6$ <p>If I_Q is negative, the limit can be calculated with the following equation:</p> $\text{MAX_LIMIT_IQ, bits}[11:0] = 2^{12} - (I_Q \times 1.5 \times 0.01 \times K_{AD} \times 1024 / 1.6)$ <p>Where I_Q is the torque current (in A), and K_{AD} is the amplifier gain's coefficient for current-sensing. The default value is 2.</p> |

Torque Command

| 0x2F: IQ_CMD | | | |
|--------------|----------|---------|--|
| Bits | Name | Default | Description |
| 15:12 | RESERVED | 0h | Unused. |
| 11:0 | IQ_CMD | 000Ah | <p>Sets the torque current .</p> <p>If I_Q is positive, the value can be calculated with the following equation:</p> $\text{IQ_CMD, bits}[11:0] = I_Q \times 1.5 \times 0.01 \times K_{AD} \times 1024 / 1.6$ <p>If I_Q is negative, the value can be calculated with the following equation:</p> $\text{IQ_CMD, bits}[11:0] = 2^{12} - (I_Q \times 1.5 \times 0.01 \times K_{AD} \times 1024 / 1.6)$ <p>Where I_Q is the torque current (in A), and K_{AD} is the amplifier gain's coefficient for current-sensing. The default value is 2.</p> |

Torque Loop Settings

| 0x2D: T_MAX_SPD | | | |
|-----------------|-----------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | T_MAX_SPD | 0064h | Sets the maximum speed in torque operating mode (in LSB / 100µs, with 2 ¹⁶ LSBs per revolution). In the calculation below, the speed limit is set to 3,000rpm: $T_MAX_SPD = 3,000(\text{rpm}) \times 2^{16} / 60 / 10,000$ |

| 0x2E: ANTI_TORQUE_GAIN | | | |
|------------------------|------------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | ANTI_TORQUE_GAIN | 000Ah | Sets the anti-saturation gain for the speed limit in torque mode. It is recommended to use MotionLAB software to set the loop parameters. |

| 0x43: CURRENT_KP | | | |
|------------------|------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | CURRENT_KP | 3BB5h | Sets the proportional gain setting for the torque loop. It is recommended to use MotionLAB software to set the loop parameters. |

| 0x44: CURRENT_KI | | | |
|------------------|------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | CURRENT_KI | 2BA6h | Sets the integral gain for the torque loop. It is recommended to use MotionLAB software to set the loop parameters. |

Homing Mode

| 0x30: DO1_FUNCTION | | | |
|--------------------|--------------|---------|---------------------|
| Bits | Name | Default | Description |
| 15:0 | DO1_FUNCTION | 0 | 0: PEND 1: ALARM |

| 0x31: DI2_FUNCTION | | | |
|--------------------|--------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | DI2_FUNCTION | 0 | 0: STEP 1: Home switch 2: Negative switch 3: Positive switch |

| 0x32: DI1_FUNCTION | | | |
|--------------------|--------------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | DI1_FUNCTION | 0 | 0: DIR 1: Home switch 2: Negative switch 3: Positive switch |

| 0x33: DI3_FUNCTION | | | |
|--------------------|--------------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | DI3_FUNCTION | 0 | 0: ENA 1: Home switch 2: Negative switch 3: Positive switch |

| 0x35: IO_POLARITY | | | |
|--------------------------|--------------|----------------|---------------------------------|
| Bits | Name | Default | Description |
| 15:4 | Reserved | 0 | Unused. |
| 3 | DI3_POLARITY | 1 | 0: None inverted 1: Inverted |
| 2 | DI1_POLARITY | 1 | 0: None inverted 1: Inverted |
| 1 | DI2_POLARITY | 1 | 0: None inverted 1: Inverted |
| 0 | DO1_POLARITY | 1 | 0: None inverted 1: Inverted |

| 0x39: HOMING_METHOD | | | |
|----------------------------|---------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | HOMING_METHOD | 0 | -3: Homing with the set torque (clockwise) -2: Homing with the set torque (counterclockwise) -1: Reserved 0: No homing operation required 1–35: Methods 1–35 (see Table 12 on page 15 for more details) |

| 0x3A: HOMING_SPEED_SWITCH | | | |
|----------------------------------|---------------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | HOMING_SPEED_SWITCH | 0 | Sets the speed during the search for a switch. The unit is in LSB / 100µs, where $LSB / 100\mu s = rpm \times 2^{16} / 60 / 10,000$. |

| 0x3B: HOMING_SPEED_ZERO | | | |
|--------------------------------|-------------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | HOMING_SPEED_ZERO | 0 | Sets the speed during the search for zero. The unit is in LSB / 100µs, where $LSB / 100\mu s = rpm \times 2^{16} / 60 / 10,000$. |

| 0x3C: HOMING_TORQUE | | | |
|----------------------------|---------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | HOMING_TORQUE | 0 | Sets the torque limit during homing, calculated with the following equation: $HOMING_TORQUE = I_Q \times 1.5 \times 0.01 \times K_{AD} \times 1024 / 1.6$ Where I_Q is the torque current (in A), and K_{AD} is the amplifier gain's coefficient for current-sensing. The default value is 2. |

| 0x3D: HOMING_STALL_TIME | | | |
|--------------------------------|-------------------|----------------|-------------------------------|
| Bits | Name | Default | Description |
| 15:0 | HOMING_STALL_TIME | 0 | The unit for this time is ms. |

| 0x45: HOMING_ACCE | | | |
|-------------------|-------------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | HOMING_ACCE | 0 | Sets the acceleration and deceleration during homing (the unit is in LSB / 100µs / 100µs, with 2 ¹⁶ LSBs per revolution). Calculate the deceleration with N (in rpm/ms) using the following equation: $\text{Homing_ACCE} = N(\text{rpm/ms}) \times 2^{16} \times 2^{16} / 6,000,000$ |

| 0x48: HOMING_OFFSET_ROUND | | | |
|---------------------------|---------------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | HOMING_OFFSET_ROUND | 0 | Sets the homing offset (higher 16 bits) (see 0x49: HOMING_OFFSET_ANGLE below for more details). |

| 0x49: HOMING_OFFSET_ANGLE | | | |
|---------------------------|---------------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | HOMING_OFFSET_ANGLE | 0 | Sets the homing offset (lower 16 bits), which is the difference between the zero position for the application and the machine home position (found during homing). Once the homing is completed, the zero position is offset from the homing position by adding the home offset to the home position. All the subsequent absolute moves shall be taken relative to this new zero position. <div style="text-align: center; margin-top: 10px;"> </div> |

Operating Mode

| 0x34: CONFIG | | | |
|--------------|--------------|---------|---|
| Bits | Name | Default | Description |
| 15:12 | MODE | 0h | Selects the operation mode. 0: Speed mode 1: Position mode 2: Torque mode 3: Homing Others: Reserved |
| 11:10 | RESERVED | 0h | Reserved |
| 9 | FEED_FORWARD | 0h | Enables the feed-forward function. 0: Disabled 1: Enabled |
| 8 | SCURVE | 0h | Enables the S-curve function. 0: Disabled. The position reference profile is the ramp profile 1: Enabled |
| 7 | NSTEP_TYPE | 0h | 0: NSTEP is determined by the register value 1: NSTEP is determined by the on-board switch SW1 |

| | | | |
|-----|--------------|----|--|
| 6 | PWM_MODE | 0h | Defines the three-phase bridge PWM driver output mode. 0: Outputs six separates PWM signals to drive the three-phase bridge MOSFETs 1: EN and PWM combination mode |
| 5 | STANDBY | 1h | 0: Standby mode disabled. The motor starts to run when powered up 1: Standby mode enabled. A start command is required for start-up |
| 4 | POS_CMD_TYPE | 1h | 0: Absolute position mode 1: Incremental position mode |
| 3:2 | CMD_MODE | 0h | 00: The command source is the RS-485 interface 01: Reserved 10: The command source is the STEP/DIR input 11: The command source is the PWM/DIR input |
| 1:0 | RESERVED | 0h | Reserved. |

Protection Parameters

| 0x53: ERROR_STATUS | | | |
|---------------------------|----------|---------|---|
| Bits | Name | Default | Description |
| 15:7 | RESERVED | 0h | Unused. |
| 6 | UVLO | 0h | Indicates the under-voltage (UV) status. |
| 5 | OTP | 0h | Flag that indicates whether over-temperature protection (OTP) has been triggered. |
| 4 | OVERLOAD | 0h | Flag that indicates whether overload protection has been triggered. |
| 3 | LOCK | 0h | Flag that indicates whether lock protection has been triggered. |
| 2 | OCP | 0h | Flag that indicates whether over-current protection (OCP) has been triggered. |
| 1 | PSFT | 0h | Flag that indicates whether a power stage fault has been triggered. |
| 0 | MEMORY | 0h | Indicates the memory fault status. |

| 0x54: RETRY | | | |
|--------------------|------------|---------|--|
| Bits | Name | Default | Description |
| 15:5 | RESERVED | 0h | Unused. |
| 4 | RETRY_EN | 0h | Enables the fault retry function. 0: Disabled. Fault protections are in latch-off mode 1: Enabled. Fault protections are in retry mode |
| 3:0 | RETRY_TIME | 0h | Sets the fault retry time, calculated with the following equation: $\text{Retry time} = (\text{RETRY_TIME} + 1) \times 0.5\text{s.}$ |

| 0x55: PROTECTION | | | |
|-------------------------|---------------|---------|---|
| Bits | Name | Default | Description |
| 15:13 | RESERVED | 0h | Unused. |
| 12 | OVERLOAD_EN | 0h | Enables overload protection. |
| 11:8 | OVERLOAD_TIME | 0h | Sets the overload detection time, calculated with the following equation: $\text{Detection time} = (\text{OVERLOAD_TIME} + 1) \times 1\text{s}$ |

| | | | |
|-----|-----------|----|---|
| 7:5 | RESERVED | 0h | Unused. |
| 4 | LOCK_EN | 0h | Enables the lock protection function. 0: Disabled 1: Enabled |
| 3:0 | LOCK_TIME | 0h | Sets the lock detection time, calculated with the following equation: $\text{Detection time} = (\text{LOCK_TIME} + 1) \times 0.5\text{s}$ |

| 0x56: VDC_LIMIT | | | |
|------------------------|--------------|---------|--|
| Bits | Name | Default | Description |
| 15:1 | VDC_LIMIT | 00C7h | Sets the V_{DC} limit, calculated with the following equation $\text{VDC_LIMIT, bits}[15:1] = V_{IN_LIMIT} \times 3.887$ Where V_{IN_LIMIT} is the bus voltage protection limit (in V). |
| 0 | VDC_LIMIT_EN | 0000h | Enables the V_{DC} limit function. 0: Disabled 1: Enabled |

| 0x58: DEADTIME | | | |
|-----------------------|----------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | DEADTIME | 0008h | Sets the dead time for the half-bridge switching signal. The dead time is set by $(\text{DEADTIME} \times 25) + 12.5\text{ns}$. |

| 0x59: ADGAIN | | | |
|---------------------|----------|---------|---|
| Bits | Name | Default | Description |
| 15:4 | RESERVED | 0h | Unused. |
| 3 | ADMODE | 0h | Fixed to 0. |
| 2:0 | ADGAIN | 0002h | Sets the amplifier gain for the current-sensing voltage. 000: $K_{AD} = 12x$ 001: $K_{AD} = 8x$ 010: $K_{AD} = 7x$ 011: $K_{AD} = 6x$ 100: $K_{AD} = 5x$ 101: $K_{AD} = 4x$ 110: $K_{AD} = 3x$ 111: $K_{AD} = 2x$ |

| 0x5A: IOCP | | | |
|-------------------|----------|---------|--|
| Bits | Name | Default | Description |
| 15:10 | RESERVED | 0h | Unused. |
| 9:0 | IOCP | 03FFh | Sets the phase current OCP threshold, calculated with the following equation: $I_{OCP} = I_{LIMIT} \times 0.01 \times K_{AD} \times 1024 / 1.6$ Where I_{LIMIT} is the real phase current protection limit (in A). |

| 0x5B: V_UVLO | | | |
|---------------------|--------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | V_UVLO | 025Dh | Sets the under-voltage lockout (UVLO) threshold, calculated with the following equation: $V_UVLO, \text{ bits}[15:0] = V_{UVLO} / 3.3 \times (10 / 412) \times 4096$ Where V_{UVLO} is the target UVLO threshold (in V). |

| 0x6B: OVERTEMP | | | |
|-----------------------|----------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | OVERTEMP | 0x0055 | Set the over-temperature indication threshold (in °C). When the board reaches this threshold, the red LED flashes 6 times, pauses, and repeats the process. |

Switching Frequency

| 0x57: FSW | | | |
|------------------|------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | FSW | 0014h | Sets the switching frequency (in kHz). |

RS485 Communication

| 0x5C: RS485_ADDR | | | |
|-------------------------|------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | RS485_ADDR | 0000h | Sets the RS-485 slave address (from 0x00 to 0x7F). 0x00 is the broadcast address. |

| 0x5D: RS485_BAUDRATE | | | |
|-----------------------------|----------------|---------|---|
| Bits | Name | Default | Description |
| 15:0 | RS485_BAUDRATE | 0000h | Sets the RS-485 baud rate, calculated with following equation: $RS485_BAURRATE = f_{BPS} / 32$ Where f_{BPS} is the target baud rate. |

Servo Information

| 0x5E: TEMPERATURE | | | |
|--------------------------|-------------|---------|-----------------------------------|
| Bits | Name | Default | Description |
| 15:0 | TEMPERATURE | 0000h | Sets the PCB temperature (in °C). |

| 0x5F: POSITION, Bits[31:16] | | | |
|------------------------------------|----------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | POSITION | 0000h | Sets the higher 16 bits of the motor shaft position, which is also the motor shaft rounds. |

| 0x60: POSITION, Bits[15:0] | | | |
|-----------------------------------|----------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | POSITION | 0000h | Sets the lower 16 bits of the motor shaft position, which is also the motor shaft angle. The unit is in LSB, where 1 LSB = 360 / 65536°. |

| 0x61: SPEED | | | |
|--------------------|-------|---------|--|
| Bits | Name | Default | Description |
| 15:0 | SPEED | 0000h | Speed feedback (lower 16 bits). The negative value is represented by a complement code. The speed feedback can be calculated with the following equation: $\text{SPEED, bits}[31:0] = (\text{rpm} / 60) \times 2^{32} / 10,000$ |

| 0x63: IQ_LATCH | | | |
|-----------------------|----------|---------|--|
| Bits | Name | Default | Description |
| 15:12 | RESERVED | 0h | Unused. |
| 11:0 | IQ_LATCH | 000h | Quadrature axis current I_Q feedback. The negative value is represented by a complement code. The feedback can be calculated with the following equation: $\text{IQ_LATCH, bits}[11:0] = I_Q \times 1.5 \times K_{AD} \times 1024 / 1.6$ |

| 0x64: ID_LATCH | | | |
|-----------------------|----------|---------|--|
| Bits | Name | Default | Description |
| 15:12 | RESERVED | 0h | Unused. |
| 11:0 | ID_LATCH | 000h | Direct axis current I_D feedback. The negative value is represented by a complement code. The feedback can be calculated with the following equation: $\text{ID_LATCH, bits}[11:0] = I_D \times 1.5 \times K_{AD} \times 1024 / 1.6$ |

| 0x65: UQ_LATCH | | | |
|-----------------------|----------|---------|-----------------------------------|
| Bits | Name | Default | Description |
| 15:12 | RESERVED | 0h | Unused. |
| 11:0 | UQ_LATCH | 000h | Sets the quadrature axis voltage. |

| 0x66: UD_LATCH | | | |
|-----------------------|----------|---------|-------------------------------|
| Bits | Name | Default | Description |
| 15:12 | RESERVED | 0h | Unused. |
| 11:0 | UD_LATCH | 000h | Sets the direct axis voltage. |

| 0x6A: STATUS | | | |
|---------------------|------------|---------|---|
| Bits | Name | Default | Description |
| 15:3 | RESERVED | 0h | Unused. |
| 3 | HOMING_END | 0h | Flag that indicates whether homing is complete. |
| 2 | SPD_REACH | 0h | Sets the speed reach target flag. See register 0x29 on page 21 for more details. |
| 1 | POS_REACH | 0h | Sets the position reach target flag. See register 0x1E on page 20 for more details. |
| 0 | RUNNING | 0h | Motor running flag |

| 0x6C: VIN_SENSE | | | |
|------------------------|-------------|----------------|--|
| Bits | Name | Default | Description |
| 15:12 | RESERVED | 0h | Unused. |
| 11:0 | VIN_SENSE | 000h | Sets the DC voltage ADC sample value. The V_{IN} sense can be calculated with following equation: $VIN_SENSE, \text{ bits}[11:0] = V_{DC} / 3.3 \times (10 / 412) \times 4096.$ Where V_{DC} is the DC link voltage. |

Operating Commands

| 0x70: RUN | | | |
|------------------|-------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | RUN | 0000h | Forces the motor to stop or run. 1: Motor run 0: Motor stop |

| 0x71: BRAKE | | | |
|--------------------|-------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | BRAKE | 0000h | Forces the motor to brake or run. 1: Motor brake 0: Motor run |

| 0x73: LOAD_TO_FLASH | | | |
|----------------------------|---------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | LOAD_TO_FLASH | 0000h | Write 0x0002 to the load register values to the flash memory. |

| 0x74: LOAD_FROM_FLASH | | | |
|------------------------------|-----------------|----------------|---|
| Bits | Name | Default | Description |
| 15:0 | LOAD_FROM_FLASH | 0000h | Loads the register value from the flash memory. |

| 0x76: UPDATE_COMMAND | | | |
|-----------------------------|----------------|----------------|--|
| Bits | Name | Default | Description |
| 15:0 | UPDATE_COMMAND | 0000h | Write 0x0000 to update the speed/position command. |

REVISION HISTORY

| Revision # | Revision Date | Description | Pages Updated |
|------------|---------------|-----------------|---------------|
| 1.0 | 10/5/2022 | Initial Release | - |

Notice: The information in this document is subject to change without notice. Please contact EZmotion for current specifications. Users should warrant and guarantee that third-party Intellectual Property rights are not infringed upon when integrating EZmotion products into any application. EZmotion will not assume any legal responsibility for any said applications.